QUICK START GUIDE Wireless system setup



Setup of ventilation devices and controls using the app

General note: A maximum of 12 participants (e. g. 11 fans and 1 control unit) can be integrated into a wireless system.

1

Install the **getAir SmartControl App** on your smartphone and launch it. Select "**Setup**" and then "**Manage wireless system**". **Allow the use of Bluetooth** in the appearing prompt. Then, go to "**Set up wireless system**" and "**Start adding devices**". Follow the instructions in the app.



2

Take **your smartphone to a ventilation unit**. Remove the cover of the inner frame and open the cover of the board on the bottom left.


Press and hold the clearly visible **black button** until the **LED lights up blue once**. If the **LED lights up green and then blinks white**, the fan has been successfully connected and **will also appear in the app**.

If the device's **LED lights up red**, a connection could not be established. Try again by repeating this step.



3

Now, go one by one to the **remaining ventilation units** and follow the **instructions from step 2** to include them in the wireless system as well.



4

Once you have integrated all ventilation units into the wireless system, go to the control unit. **Press and hold the button** unit the **LED lights up blue once**. If the **LED lights up green and then blinks white**, the control unit has been successfully connected and **will also appear in the app**.

If the **LED lights up red**, a connection could not be established. Try again by repeating this step.



5

Once all ventilation units and controls are connected and displayed in the app, select "Done" in the app. The setup is now completed, and the data is distributed to all connected participants (fans and controls).

All information regarding the **WLAN setup of the ComfortControl Pro BT** control unit can be found in its **installation and operating manual** under WLAN setup.

